

Transfer

application guide

1

Peel away the excess material from around the design.

Once removed, take the application tape sheet & remove the backing liner. Place the tape over the design sheet & firmly press down using an application squeegee or bank card.



2

Carefully cut around your design



3

Turn over your cut out design & peel away the clear backing liner leaving your design on the reverse side of the application tape



4

Place the design face up onto the fabric where it is to be pressed and cover with a silicone sheet to protect the press plate.

(Grease proof paper could also be used)

5

Pre heat your heat press to 160°C and using a medium pressure, press for 15 seconds.

A domestic iron could also be used. Set your iron to the highest temperature and ensure the steam is off.

Press with the item on a hard / flat surface for 15 sec. Designs can be layered.

If layering pressing time would have to be increased. Prior testing is always recommended.



6

Remove the silicone sheet & peel away the clear application tape whilst the material is still warm.

7

WASH & CARE INSTRUCTIONS

- Wash up to 40°C on a wool / delicate cycle. 600-800 spin. Inside out.

- Tumble dry at low temp

NOTE Leave for 24 Hours before washing



Warm Peel

