



1. Peel away the excess material from the decal. Once removed, take the application tape and remove its backing liner. Place the tape over the design sheet. Flip over the decal and firmly press down on the carrier sheet using an application squeegee or bank card.

2. Carefully cut the decal using scissors.



3. Turn over your cut out decal and peel away the clear backing liner leaving your decal on the reverse side of the application tape.

4. Preheat your heat press to 160°C and preheat your area of application for 10 seconds. Position the decal face up on the area of application and cover with parchment or baking type paper on top as a cover sheet (if you wish). **DO NOT USE TEFLON**, the vinyl will not transfer properly.

5. Using a medium pressure at 160°C, press for 15 seconds.

If using a domestic iron: **DO NOT** use steam. Ensure the material is on a hard flat surface - **NOT AN IRONING BOARD**. Firmly press one area of the design at a time for 15 seconds before moving to the next unpressed part.

REMYINDER: HTV Transfer can be layered. If layering, press times will need to be slightly increased. Prior testing is recommended.

6. Remove the cover sheet and peel away the clear application tape whilst the material is still warm.

REMYINDER: Leave for 24 hours before washing or using. Wash and care instructions. Wash up to 40°C on a wool / delicate cycle. 600-800 spin. Inside out. Tumble dry at a low temperature.

