



1. Cut the image using a plotter or contour cutter. Only cut the top layer of material and not the clear carrier sheet.

**BEFORE CUTTING :** make sure the image you're cutting is reversed in your cutting software as you are cutting the reverse side of the vinyl. To check if you are cutting the reverse side, gently peel one corner of the vinyl to reveal the clear carrier sheet. The clear carrier sheet is always face down - you **DO NOT** cut it. Only the top layer of the vinyl is cut not the clear carrier sheet.



**REMEMINDER:** Make sure the image is reversed in your cutting software.



2. Weed away any excess material until the finished design is left on the clear carrier sheet.

What is 'weeding'? : The process of removing the excess vinyl from a design that has been cut.



**TIP:** Weeding tweezers or tool will make this process quick and easy.

3. Preheat the area of application that you're placing the vinyl on for 10 seconds to remove any moisture. Place the vinyl design facing up as you'd expect it to view the finished design. Once positioned, if you wish, you can use parchment or baking type paper on top as a cover sheet. **DO NOT USE TEFLON**, the vinyl will not transfer properly.



**REMEMINDER:** Turbo Press can be layered. If layering, press times will need to be slightly increased. Prior testing is recommended. Layering is not recommended with Gold metallic, Silver Metallic & Neon colours in the Turbo series.

4. Turbo Press is suitable for cotton, polycotton and nylon fabrics. Using a strong pressure the following press settings can be used for cotton and polycotton:

130°C — 5 secs

150°C — 4 secs

160°C — 3 secs



For nylon, use a medium pressure at 150°C. Press on nylon for 5 seconds. Remove the clear carrier sheet, place cover sheet over vinyl and press for a further 10 seconds.



If using a domestic iron: **DO NOT** use steam. Ensure the material is on a hard flat surface - **NOT AN IRONING BOARD**. Gently iron the area of application to remove any moisture or creases. With the iron set to the highest temperature, very firmly press the iron onto the cover sheet for 3 seconds. Carefully take off the cover sheet (if using one) and peel off the clear carrier sheet. Re-place the cover sheet over the vinyl and iron for 1 second increments until the transfer is fully pressed.



For nylon fabrics, reduce the heat to medium and increase the initial iron press time to 4 seconds. If when peeling the clear carrier sheet a part of the design hasn't stuck, firmly repress that area for only 2 seconds. (Repeat in 1 second increments until the transfer is fully pressed if necessary on any areas not fully applied only.)

5. Remove the cover sheet (if used). Peel away the clear carrier sheet whilst the material is still warm.



Leave for 24 hours before washing or using.

Machine Washable cotton and polycotton 60°C, Nylon 40°C. Low tumble dry and dry clean cotton and polycotton only.